

# 散氣盤鞍座安裝手冊

內牙楔型上蓋(散氣盤三通鞍座)\*1  
內牙楔型底座(散氣盤三通鞍座)\*1  
楔型固定塊\*1  
鞍座墊片 PR-080\*1



# 步驟1



HOLDING 鑽孔

# 步驟2



HOLE SIZE : 19-21 MM

# 步驟3



# 步驟4



GASKET

步驟 5



步驟 6



CLAMP

步驟 7



FITTING

步驟 8





RUBBER HAMMER

步驟9



步驟10

FINISHED



組裝完成

PRODUCT QC SADDLE  
3"(89-90 MM) & 4"(114 MM)